

GS450h


Emergency Response
Quick Guide













MY: 2016 -




**LEXUS
HYBRID
DRIVE**

**HV BATTERY
Ni-MH**




	IG/POWER SW		Fuse Box		12V Battery
	Airbag (incl. Inflator)		Inflator		High Voltage Battery
	High Voltage Components		Fuel Tank		Gas-filled Damper
	Seat Belt Pretensioner (Gas Generator)		Structural Reinforcements		Airbag Computer


Disable Vehicle




or



Access to 12V Battery



Towing Information



More details, please refer to "Emergency Response Guide".
<http://www.techinfo.toyota.com>