
















PRIUS C

Emergency Response
Quick Guide

MY: 2015 -




	IG/POWER SW		Fuse Box		12V Battery
	Airbag (incl. Inflator)		Inflator		High Voltage Battery
	High Voltage Components		Fuel Tank		Gas-filled Damper
	Seat Belt Pretensioner (Gas Generator)		Structural Reinforcements		Airbag Computer
-	-	-	-	-	-


PRIUSC10_LHD_1




Disable Vehicle




or



Access to 12V Battery



Towing Information



More details, please refer to "Emergency Response Guide".
<http://www.techinfo.toyota.com>